Basket
Indoor club chair
by Nanna and Jørgen Ditzel

kettal

Indoor club chair

Designers
Nanna and Jørgen Ditzel

Collection
Basket

Reference
KS1000200

Kettal edits the Basket chair, created in the 1950s by Danish designers Nanna and Jørgen Ditzel. The Basket chair, made from oak, comes in its original version created by the Ditzel, hand-braided in wicker, and in an outdoor version, made from artificial fibre and teak.



kettal

Indoor club chair

Designer
Nanna and Jørgen Ditzel

Collection
Basket

Reference
KS1000200

Maintenance

Clean with mild soap using a sponge or cloth. Be gentle during the cleaning process; avoid aggressive scrubbing of the fabric. After cleaning, ensure you remove any excess soap.

For stubborn stains, use diluted household bleach. Act promptly to clean stains; the longer they linger, the more challenging they become to remove.

After cleaning, steam iron the fabric using only steam. Be cautious not to place the iron directly on the fabric, as it may cause damage.

Finishes

Click here or scan the following QR code.

Other Characteristics

Indoor only

kettal